AXIOMTEK

MANO871 Series

Intel® Socket 1155 Core™ i7 / Core™ i5 / Core™ i3 / Celeron® Processor All-In-One Mini ITX Board with HDMI / DVI-I / LVDS

User's Manual

Disclaimers

This manual has been carefully checked and believed to contain accurate information. Axiomtek Co., Ltd. assumes no responsibility for any infringements of patents or any third party's rights, and any liability arising from such use.

Axiomtek does not warrant or assume any legal liability or responsibility for the accuracy, completeness or usefulness of any information in this document. Axiomtek does not make any commitment to update the information in this manual.

Axiomtek reserves the right to change or revise this document and/or product at any time without notice.

No part of this document may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of Axiomtek Co., Ltd.

CAUTION

If you replace wrong batteries, it causes the danger of explosion. It is recommended by the manufacturer that you follow the manufacturer's instructions to only replace the same or equivalent type of battery, and dispose of used ones.

©Copyright 2013 Axiomtek Co., Ltd.

All Rights Reserved

August 2013, Version A2

Printed in Taiwan

ESD Precautions

Computer boards have integrated circuits sensitive to static electricity. To prevent chipsets from electrostatic discharge damage, please take care of the following jobs with precautions:

- Do not remove boards or integrated circuits from their anti-static packaging until you are ready to install them.
- Before holding the board or integrated circuit, touch an unpainted portion of the system unit chassis for a few seconds. It discharges static electricity from your body.
- Wear a wrist-grounding strap, available from most electronic component stores, when handling boards and components.

Trademarks Acknowledgments

Axiomtek is a trademark of Axiomtek Co., Ltd.

Windows® is a trademark of Microsoft Corporation.

AMI is a trademark of American Megatrend Inc.

IBM, PC/AT, PS/2, VGA are trademarks of International Business Machines Corporation.

Intel® Core™ i7 / Core™ i5 / Core™ i3 / Celeron® are trademarks of Intel Corporation.

Winbond is a trademark of Winbond Electronics Corp.

Realtek is a trademark of Realtek Semi-Conductor Co., Ltd.

Other brand names and trademarks are the properties and registered brands of their respective owners.

Table of Contents

Disclaimers ii

ESD Precautions iii

Chapter 1 Introduction 1

1.1 Features 1
1.2 Specifications 2
1.3 Utilities Supported 3

Chapter 2 Board and Pin Assignments 5

2.1 Board Dimensions and Fixing Holes 5
2.2 Board Layout 7
2.3 Jumper and Switch Settings 9

2.3.1 Restore BIOS Optimal Defaults (JP1) 10
2.3.2 LVDS Voltage Selection (JP2 and JP3) 10
2.3.3 USB Port 4 and 5 Power Selection (JP4) 10
2.3.4 SATA/SATADOM Selection (JP5) 10
2.3.5 LVDS Backlight Control Mode Setting (JP7) 10
2.3.6 Auto Power On (JP8) 11
2.3.7 COM1 Data/Power Selection (JP10) 11
2.3.8 COM1 RS-232/422/485 Mode Setting (JP11, JP12, JP14) 11
2.3.9 COM3 Data/Power Selection (JP13) 11
2.3.10 PCI-Express Bifurcation Setting (SW1) 12
2.3.11 Mini Card Interface Selection (JP16) 12

2.4 Connectors 13

2.4.1 ATX Power Connectors (CN2 and ATX1) 14
2.4.2 Serial ATA Connectors (CN3, CN4, SATA1 and SATA2) 15
2.4.3 LVDS Connector (CN6) 16
2.4.4 Inverter Connectors (CN7) 18
2.4.5 USB Connectors (CN8 and CN9) 18
2.4.6 LAN and USB Connectors (CN10 and CN11) 19
2.4.7 DVI-I Connector (CN12) 20
2.4.8 COM Connectors (CN13, CN14 and CN15) 21
2.4.9 HD Audio Jack (CN16) 21
2.4.10 Internal Audio Connector (CN17) 22
2.4.11 HDMI Connector (CN18) 22
2.4.12 PCI-Express Mini Card and mSATA Connector (SCN2) 23
2.4.13 FAN Connectors (FAN1 and FAN2) 24
2.4.14 Front Panel Connector (JP6) 24
2.4.15 Digital I/O Connector (JP9) 25

Chapter 3 Hardware Installation 27

3.1 Installing the Processor 27
3.2 Installing the Memory 33

Chapter 4 Hardware Description 35

4.1 Microprocessors 35
4.2 BIOS 35
4.3 System Memory 35
4.4 I/O Port Address Map 36
4.5 Interrupt Controller (IRQ) Map 38
4.6 Memory Map 39

Chapter 5 AMI BIOS Setup Utility 41

5.1 Starting 41
5.2 Navigation Keys 41
5.3 Main Menu 42
5.4 Advanced Menu 43
5.5 Chipset Menu 52
5.6 Boot Menu 56
5.7 Security Menu 57
5.8 Save & Exit Menu 58

Appendix A Watchdog Timer 61

About Watchdog Timer 61
How to Use Watchdog Timer 61

Appendix B Digital I/O 63

Using Digital Output Function 63
Using Digital Input Function 63

Appendix C Configuring SATA for RAID 65

Configuring SATA Hard Drive(s) for RAID Function 65

Appendix D Intel® iAMT Settings 75

Entering MEBx 75
Set and Change Password 76
Intel® iAMT Web Console 78

This page is intentionally left blank.

Chapter 1
Introduction



The MANO871 is a Mini ITX board with LGA1155 socket for Intel® Core™ i7 / Intel® Core™ i5 / Intel® Core™ i3 / Intel® Celeron® (G6950) desktop processor with 22nm technology. The board integrates Intel® Q77 chipset that delivers outstanding system performance through high-bandwidth interfaces, multiple I/O functions for interactive applications and various embedded computing solutions. There are two 204-pin DDR3 SO-DIMM sockets for dual channel DDR3 1333/1600MHz memory with maximum capacity up to 16GB; assuming dual channel mode of two 8GB double-sided unbuffered, non-ECC SO-DIMM memory configuration. The board also features Gigabit Ethernet, two SATA 3.0 ports (support SATA RAID 0/1/5/10 by Q77) at maximum transfer rate up to 6Gb/s, two SATA 2.0 ports at maximum transfer rate up to 3Gb/s, four USB 3.0 and four USB 2.0 high speed compliant ports that can achieve the best stability and reliability for industrial applications.

1.1 Features

- LGA1155 socket 3rd Generation Intel® Core™ i7 / i5 / i3 / Celeron® processors
- 2 DDR3 1333/1600MHz up to 16GB
- PCI-Express Gen. 3 supported
- 2 SATA-600 with RAID 0, 1, 5 and 10 supported
- 2 SATA-300 with 1 SATADOM supported
- 4 USB 3.0 supported
- iAMT 8.0 supported
- TPM 1.2 supported
- Dual view display

1.2 Specifications

- **CPU**
  - Intel® Core™ i7 desktop processor.
  - Intel® Core™ i5 desktop processor.
  - Intel® Core™ i3 desktop processor.
  - Intel® Celeron® desktop processors.

- **System Chipset**
  - Intel® Q77.

- **CPU Socket**
  - LGA1155.

- **DRAM Transfer Rate**
  - 1333/1600MHz.

- **BIOS**
  - AMI BIOS via SPI interface with socket.

- **System Memory**
  - Two 204-pin unbuffered DDR3 SO-DIMM sockets.
  - Maximum up to 16GB DDR3 1333/1600MHz memory with two SO-DIMMs using 8GB memory technology.

- **Onboard Multi I/O**
  - Controller: Nuvoton NCT6627UD.
  - Serial ports: Three RS-232 ports (COM2/3/4) and one RS-232/422/485 port (COM1).

- **SATADOM (Optional)**
  - One SATADOM supported; co-layout with a SATA-300 socket (according to SATA 2.0 signal).

- **Serial ATA**
  - Supports SATA 3.0 and SATA 2.0.
  - Two SATA 3.0 ports (6Gb/s performance) with SATA RAID 0/1/5/10 by Q77 and two SATA 2.0 ports (3Gb/s performance).

- **USB Interface**
  - Four USB 3.0 ports with fuse protection.
  - Four USB 2.0 ports with fuse protection.

- **Display**
  - One HDMI.
  - One LVDS 24-bit dual channel.
  - One DVI-I.

Note: ***Due to Intel design limitation and BIOS default option, under DOS only VGA display is supported.***

- **Watchdog Timer**
  - 1~255 seconds; up to 256 levels.

- **Expansion Interface**
  - One PCI-Express x16 slot.

- **Ethernet**
  - LAN1 – Intel® 82579LM supports 10/100/1000Mbps.
  - LAN2 – Intel® 82583V supports 10/100/1000Mbps.

- **Audio**
  - HD audio compliant (with line/speaker-out and MIC-in) via ALC662.
  - Internal audio feature for speaker-out via wafer connector.

- **Power Management**
  - ACPI (Advanced Configuration and Power Interface).

- **Form Factor**
  - Mini ITX form factor.

Note: ***All specifications and images are subject to change without notice.***

1.3 Utilities Supported

- Chipset driver
- Ethernet driver
- Graphics driver
- Audio driver

This page is intentionally left blank.

Chapter 2
Board and Pin Assignments

2.1 Board Dimensions and Fixing Holes



Top Side



Bottom Side

2.2 Board Layout



Top Side



I/O Bracket



Bottom Side

2.3 Jumper and Switch Settings

Jumper is a small component consisting of jumper clip and jumper pins. Install jumper clip on 2 jumper pins to close. And remove jumper clip from 2 jumper pins to open. The following illustration shows how to set up jumper.



Before applying power to MANO871 Series, please make sure all of the jumpers and switch are in factory default position. Below you can find a summary table and onboard default settings.

Jumper and Switch	Description		Setting
JP1	Restore BIOS Optimal Defaults Default: Normal Operation		1-2 close
JP2 (Optional)	LVDS Voltage Selection		All open
JP3	LVDS Voltage Selection Default: +3.3V		1-2 close
JP4	USB Port 4 and 5 Power Selection Default: Standby Power +5V		1-2 close
JP5	SATA/SATADOM Selection Default: SATA		2-3 close
JP7	LVDS Backlight Control Mode Setting Default: PWM Mode		1-2 close
JP8	Auto Power On Default: Disable		1-2 close
JP10	COM1 Data/Power Selection Default: RS-232 Data	CN15A Pin 1: DCD	3-5 close
		CN15A Pin 9: RI	4-6 close
JP11	COM1 RS-232/422/485 Mode Setting Default: RS-232		3-5, 4-6 close
JP12			1-2 close
JP14			3-5, 4-6 close
JP13	COM3 Data/Power Selection Default: RS-232 Data	CN13 Pin 1: DCD	3-5 close
		CN13 Pin 8: RI	4-6 close
JP16	Mini Card Interface Selection Default: PCI-Express Interface		1-2 Close
SW1	PCI-Express Bifurcation Setting Default: One x16 PCI-Express		SW1-1 OFF
			SW1-2 OFF

2.3.1 Restore BIOS Optimal Defaults (JP1)

Put jumper clip to pin 2-3 for a few seconds then move it back to pin 1-2. Doing this procedure can restore BIOS optimal defaults.

Function	Setting
Normal operation (Default)	1-2 close
Restore BIOS optimal defaults	2-3 close



2.3.2 LVDS Voltage Selection (JP2 and JP3)

The board supports voltage selection for flat panel displays. Use JP3 to set LVDS connector (CN6) pin 1~6 VCCM to +3.3V or +5V voltage level. Use JP2 (optional) to set LVDS connector (CN6) pin 1~6 VCCM to +12V voltage level. To prevent hardware damage, before connecting please make sure that the input voltage of LVDS flat panel is correct.

Function	JP3 Setting
+3.3V level (Default)	1-2 close
+5V level	2-3 close

Function	JP2 Setting
+12V level (Optional)	1-2 close



2.3.3 USB Port 4 and 5 Power Selection (JP4)

Use JP4 for setting USB power signal on connector CN9 to standby power or system power.

Function	Setting
Standby power +5V level (Default)	1-2 close
System power +5V level	2-3 close

2.3.4 SATA/SATADOM Selection (JP5)

Use JP5 for enabling connector CN4 to support SATA or SATADOM.

Function	Setting
SATADOM	1-2 close
SATA (Default)	2-3 close



2.3.5 LVDS Backlight Control Mode Setting (JP7)

The JP7 is enabled to select PWM or DC control mode for inverter connector (CN7). These two control modes are for adjusting LVDS brightness.

Function	Setting
PWM mode (Default)	1-2 close
DC mode	3-4 close



2.3.6 Auto Power On (JP8)

If JP8 is enabled for AC power input, the system will be automatically power on without pressing soft power button. If JP8 is disabled for AC power input, it is necessary to manually press soft power button to power on the system.

Function	Setting
Disable auto power on (Default)	1-2 close
Enable auto power on	2-3 close



2.3.7 COM1 Data/Power Selection (JP10)

The COM1 port has +5V level power capability on DCD and +12V level on RI by setting this jumper. When COM1 is set to +5V or +12V level, please make sure the communication mode is RS-232 (see section 2.3.8).

Function	Setting
Power: Set CN15A pin 1 to +5V level	1-3 close
Data: Set CN15A pin 1 to DCD (Default)	3-5 close
Power: Set CN15A pin 9 to +12V level	2-4 close
Data: Set CN15A pin 9 to RI (Default)	4-6 close



2.3.8 COM1 RS-232/422/485 Mode Setting (JP11, JP12, JP14)

Use these jumpers to set COM1 port to operate as RS-232, RS-422 or RS-485 communication mode. When these jumpers are set to operate as RS-422 or RS485 mode, please make sure COM1 is on data mode (see section 2.3.7)

Function	Setting
RS-232 mode (Default)	JP11 3-5, 4-6 close JP12 1-2 close JP14 3-5, 4-6 close
RS-422 mode	JP11 1-3, 2-4 close JP12 3-4 close JP14 1-3, 2-4 close
RS-485 mode	JP11 1-3, 2-4 close JP12 5-6 close JP14 1-3, 2-4 close



2.3.9 COM3 Data/Power Selection (JP13)

The COM3 port has +5V level power capability on DCD and +12V level on RI by setting this jumper.

Function	Setting
Power: Set CN13 pin 1 to +5V level	1-3 close
Data: Set CN13 pin 1 to DCD (Default)	3-5 close
Power: Set CN13 pin 8 to +12V level	2-4 close
Data: Set CN13 pin 8 to RI (Default)	4-6 close



2.3.10 PCI-Express Bifurcation Setting (SW1)

SW1 is for PCI-Express bifurcation setting. See table below for detailed information.

Function	Setting
One x16 PCI-Express (Default)	SW1-1 OFF SW1-2 OFF
Two x8 PCI-Express	SW1-1 OFF SW1-2 ON
One x8, two x4 PCI-Express	SW1-1 ON SW1-2 ON
Reserved	SW1-1 ON SW1-2 OFF

SW1

2.3.11 Mini Card Interface Selection (JP16)

Use JP16 for setting Mini Card to PCI-Express or mSATA .

Function	Setting
PCI-Express Interface (Default)	1-2 close
mSATA Interface	2-3 close

2.4 Connectors

Signals go to other parts of the system through connectors. Loose or improper connection might cause problems, please make sure all connectors are properly and firmly connected. Here is a summary table which shows all connectors on the hardware.

Connector	Description
CN1	PCI-Express x16 Slot
CN2	24-pin ATX Power Connector
CN3	Serial ATA 2.0 port 2 Connector
CN4	Serial ATA 2.0 port 3 Connector (Optional for SATADOM)
CN6	LVDS Connector
CN7	Inverter Connector
CN8	USB 2.0 Port 6 and 7 Connector
CN9	USB 2.0 Port 4 and 5 Connector
CN10	LAN1 (WG82579LM), USB 3.0 Port 2 and 3 Connector
CN11	LAN2 (WG82583V), USB 3.0 Port 0 and 1 Connector
CN12	DVI-I Connector
CN13	COM3 Connector
CN14	COM4 Connector
CN15	COM1 and COM2 Connector
CN16	HD Audio Jack
CN17	Internal Audio Connector
CN18	HDMI Connector
SCN2	PCI-Express Mini Card and mSATA Connector
ATX1	4-pin +12V ATX Power Connector
FAN1	CPU Fan Connector
FAN2	System Fan Connector
JP6	Front Panel Connector
JP9	Digital I/O Connector
SATA1~2	Serial ATA 3.0 port 0 and 1 Connectors
DIMM1~2	DDRIII SO-DIMM Connectors

2.4.1 ATX Power Connectors (CN2 and ATX1)

Steady and sufficient power can be supplied to all components on the board by connecting power connector. Please make sure all components and devices are properly installed before connecting the power connector.

External power supply plug fits into this connector in only one orientation. Properly press down power supply plug until it completely and firmly fits into this connector. Loose connection may cause system instability.

The CN2 is a 24-pin ATX power connector. Its pin assignments are given in table below.

Pin	Signal	Pin	Signal
1	3.3V	13	3.3V
2	3.3V	14	-12V
3	GND	15	GND
4	+5V	16	PS_ON
5	GND	17	GND
6	+5V	18	GND
7	GND	19	GND
8	PWR OK	20	-5V
9	5VSB	21	+5V
10	+12V	22	+5V
11	+12V	23	+5V
12	3.3V	24	GND



The ATX1 is a 4-pin +12V ATX power connector for connecting CPU core voltage, see table below.

Pin	Signal	Pin	Signal
1	GND	3	+12V
2	GND	4	+12V



2.4.2 Serial ATA Connectors (CN3, CN4, SATA1 and SATA2)

These Serial Advanced Technology Attachment (Serial ATA or SATA) connectors are for high-speed SATA interfaces. They are computer bus interfaces for connecting to devices such as hard disk drives.

This board has two SATA 2.0 ports (CN3 and CN4) with 3Gb/s performance and two SATA 3.0 ports (SATA1 and SATA2) with 6Gb/s performance. Note that CN4 can be set to support SATADOM by configuring jumper JP5 (see section 2.3.4).

Pin	CN3/SATA1/SATA2 Signal
1	GND
2	SATA_TX+
3	SATA_TX-
4	GND
5	SATA_RX-
6	SATA_RX+
7	GND

Pin	CN4 Signal
1	GND
2	SATA_TX+
3	SATA_TX-
4	GND
5	SATA_RX-
6	SATA_RX+
7	GND(DEFAULT)/+5V



2.4.3 LVDS Connector (CN6)

This board has a 40-pin connector (CN6) for LVDS LCD interface. It is strongly recommended to use the matching JST SHDR-40VS-B 40-pin connector for LVDS interface. Pin 1~6 VCCM can be set to +3.3V, +5V or +12V level by JP2 and JP3 (see section 2.3.2).

18-bit single channel

Pin	Signal	Pin	Signal
1	VCCM	2	VCCM
3	VCCM	4	VCCM
5	VCCM	6	VCCM
7	EDID DATA	8	EDID CLK
9	GND	10	GND
11	N.C.	12	N.C.
13	N.C.	14	N.C.
15	GND	16	GND
17	N.C.	18	N.C.
19	N.C.	20	N.C.
21	GND	22	GND
23	Channel A D0-	24	N.C.
25	Channel A D0+	26	N.C.
27	GND	28	GND
29	Channel A D1-	30	N.C.
31	Channel A D1+	32	N.C.
33	GND	34	GND
35	Channel A D2-	36	Channel A CLK-
37	Channel A D2+	38	Channel A CLK+
39	GND	40	GND



24-bit single channel

Pin	Signal	Pin	Signal
1	VCCM	2	VCCM
3	VCCM	4	VCCM
5	VCCM	6	VCCM
7	EDID DATA	8	EDID CLK
9	GND	10	GND
11	N.C.	12	N.C.
13	N.C.	14	N.C.
15	GND	16	GND
17	N.C.	18	N.C.
19	N.C.	20	N.C.
21	GND	22	GND
23	Channel A D0-	24	N.C.
25	Channel A D0+	26	N.C.
27	GND	28	GND
29	Channel A D1-	30	Channel A D3-
31	Channel A D1+	32	Channel A D3+
33	GND	34	GND
35	Channel A D2-	36	Channel A CLK-
37	Channel A D2+	38	Channel A CLK+
39	GND	40	GND

18-bit dual channel

Pin	Signal	Pin	Signal
1	VCCM	2	VCCM
3	VCCM	4	VCCM
5	VCCM	6	VCCM
7	EDID DATA	8	EDID CLK
9	GND	10	GND
11	N.C.	12	Channel B D0-
13	N.C.	14	Channel B D0+
15	GND	16	GND
17	Channel B CLK-	18	Channel B D1-
19	Channel B CLK+	20	Channel B D1+
21	GND	22	GND
23	Channel A D0-	24	Channel B D2-
25	Channel A D0+	26	Channel B D2+
27	GND	28	GND
29	Channel A D1-	30	N.C.
31	Channel A D1+	32	N.C.
33	GND	34	GND
35	Channel A D2-	36	Channel A CLK-
37	Channel A D2+	38	Channel A CLK+
39	GND	40	GND

24-bit dual channel

Pin	Signal	Pin	Signal
1	VCCM	2	VCCM
3	VCCM	4	VCCM
5	VCCM	6	VCCM
7	EDID DATA	8	EDID CLK
9	GND	10	GND
11	Channel B D3-	12	Channel B D0-
13	Channel B D3+	14	Channel B D0+
15	GND	16	GND
17	Channel B CLK-	18	Channel B D1-
19	Channel B CLK+	20	Channel B D1+
21	GND	22	GND
23	Channel A D0-	24	Channel B D2-
25	Channel A D0+	26	Channel B D2+
27	GND	28	GND
29	Channel A D1-	30	Channel A D3-
31	Channel A D1+	32	Channel A D3+
33	GND	34	GND
35	Channel A D2-	36	Channel A CLK-
37	Channel A D2+	38	Channel A CLK+
39	GND	40	GND

***Note*: See section 5.5 for LVDS resolution setting in BIOS menu.**

2.4.4 Inverter Connectors (CN7)

The CN7 is DF13-8P-1.25V 8-pin connector for inverter. We strongly recommend you to use the matching DF13-8S-1.25C connector to avoid malfunction.

Pin	Signal
1	VBL1 (+12V level)
2	VBL1 (+12V level)
3	VBL2 (+5V level)
4	VBL_ENABLE
5	GND
6	GND
7	GND
8	LVDS_BRICTL



2.4.5 USB Connectors (CN8 and CN9)

The CN8 and CN9 are USB connectors carrying USB port 6 and 7 and USB port 4 and 5, respectively. They are for installing versatile USB 2.0 compliant interface peripherals. These connectors are designed with +5V level standby power which can provide power when system is in suspend mode. Note that the power signal on CN9 can also be set to system power (see section 2.3.3).

Pin	Signal	Pin	Signal
1	USB VCC (+5V level standby power)	2	USB VCC (+5V level standby power)
3	USB DX-	4	USB DY-
5	USB DX+	6	USB DY+
7	GND	8	GND
9	GND	10	GND

CN8/CN9



2.4.6 LAN and USB Connectors (CN10 and CN11)

The board comes with two high performance plug and play ethernet interfaces (RJ-45) which are fully compliant with the IEEE 802.3 standard. Connection can be established by plugging one end of the ethernet cable into this RJ-45 connector and the other end to a 1000/100/10-Base-T hub.

The Universal Serial Bus (compliant with USB 3.0 (5Gb/s)) connectors on the rear I/O are for installing USB peripherals such as keyboard, mouse, scanner, etc. Note that the CN10 carries LAN1, USB 3.0 port 2 and 3 signals while CN11 carries LAN2, USB 3.0 port 0 and 1 signals.

Pin	LAN1 Signal (WG82579LM)	Pin	LAN1 Signal (WG82579LM)
L1	MDI0+	L5	MDI2+
L2	MDI0-	L6	MDI2-
L3	MDI1+	L7	MDI3+
L4	MDI1-	L8	MDI3-
A	100 LAN LED (Green)/ 1000 LAN LED (Orange)		
B	Active LED		

CN10



Pin	USB Signal	Pin	USB Signal
1	USB_VCC (+5V level standby power)	10	USB_VCC (+5V level standby power)
2	USB_Data2-	11	USB_Data3-
3	USB_Data2+	12	USB_Data3+
4	GND	13	GND
5	SSRX2-	14	SSRX3-
6	SSRX2+	15	SSRX3+
7	GND	16	GND
8	SSTX2-	17	SSTX3-
9	SSTX2+	18	SSTX3+

Pin	LAN2 Signal (WG82583V)	Pin	LAN2 Signal (WG82583V)
L1	MDI0+	L5	MDI2+
L2	MDI0-	L6	MDI2-
L3	MDI1+	L7	MDI3+
L4	MDI1-	L8	MDI3-
A	100 LAN LED (Green)/ 1000 LAN LED (Orange)		
B	Active LED		

CN11



Pin	USB Signal	Pin	USB Signal
1	USB_VCC (+5V level standby power)	10	USB_VCC (+5V level standby power)
2	USB_Data0-	11	USB_Data1-
3	USB_Data0+	12	USB_Data1+
4	GND	13	GND
5	SSRX0-	14	SSRX1-
6	SSRX0+	15	SSRX1+
7	GND	16	GND
8	SSTX0-	17	SSTX1-
9	SSTX0+	18	SSTX1+

2.4.7 DVI-I Connector (CN12)

The board comes with a high rise DVI-I (Digital Video Interface – Integrated) interface providing transmission of fast and high quality video signal between source device (e.g. graphic card) and display device (e.g. monitor). The DVI-I interface supports both digital and analog.

Pin	Signal	Pin	Signal
1	TX2-	2	TX2+
3	Ground	4	NC
5	NC	6	DVI_SPD_CLK
7	DVI_SPD DATA	8	CRT-VSYNC
9	TX1-	10	TX1+
11	Ground	12	NC
13	NC	14	VGAVCC
15	Ground	16	FPDETECT
17	TX0-	18	TX0+
19	Ground	20	NC
21	NC	22	Ground
23	TXC+	24	TXC-
C1	CRT-RED	C2	CRT-GREEN
C3	CRT-BLUE	C4	CRT-HSYNC
C5	VGAGND		



2.4.8 COM Connectors (CN13, CN14 and CN15)

The COM3 and COM4 interfaces are available through CN13 and CN14, respectively. Each of these connectors is a 2x5 pin 2.0 pitch box header, see table below for its pin assignments.

Pin	Signal
1	Data Carrier Detect (DCD)
2	Data Set Ready (DSR)
3	Receive Data (RXD)
4	Request to Send (RTS)
5	Transmit Data (TXD)
6	Clear to Send (CTS)
7	Data Terminal Ready (DTR)
8	Ring Indicator (RI)
9	Ground (GND)
10	NC

CN13/CN14



The CN15 is a double-deck DB-9 connector. The upper connector (CN15A) is for COM1 and the lower connector (CN15B) is for COM2. Note that the connectors (CN13 and CN15A) come with power capability on DCD and RI pins by setting jumpers (see section 2.3.7 and 2.3.9).

Pin	Pin	Signal
1	10	Data Carrier Detect (DCD)
2	11	Receive Data (RXD)
3	12	Transmit Data (TXD)
4	13	Data Terminal Ready (DTR)
5	14	Ground (GND)
6	15	Data Set Ready (DSR)
7	16	Request to Send (RTS)
8	17	Clear to Send (CTS)
9	18	Ring Indicator (RI)

CN15A



CN15B

2.4.9 HD Audio Jack (CN16)

The board provides a HD audio jack on the rear I/O. Install audio driver, and then attach audio devices to CN16.

Pin Color	Signal
Green	Line-out
Pink	MIC-in

2.4.10 Internal Audio Connector (CN17)

CN17 is an internal audio connector for line-out and microphone.

Pin	Signal
1	Lineout-L
2	GND
3	Lineout-R
4	GND
5	MIC-in



2.4.11 HDMI Connector (CN18)

The HDMI (High-Definition Multimedia Interface) is a compact digital interface which is capable of transmitting high-definition video and high-resolution audio over a single cable. Its interface is available through connector CN18.

Pin	Signal	Pin	Signal
1	HDMI OUT_DATA2+	2	GND
3	HDMI OUT_DATA2-	4	HDMI OUT_DATA1+
5	GND	6	HDMI OUT_DATA1-
7	HDMI OUT_DATA0+	8	GND
9	HDMI OUT_DATA0-	10	HDMI OUT_Clock+
11	GND	12	HDMI OUT_Clock-
13	CEC	14	N.C.
15	HDMI OUT_SCL	16	HDMI OUT_SDA
17	GND	18	+5V
19	HDMI_HTPLG		



2.4.12 PCI-Express Mini Card and mSATA Connector (SCN2)

SCN2 (soldered on the bottom side) is a PCI-Express Mini Card connector which supports a PCI-Express x1 link, a SATA link and a USB 2.0 link. A PCI-Express Mini Card can be applied to either PCI-Express or USB 2.0 and SATA also. It complies with PCI-Express Mini Card spec v1.2.

Pin	Signal	Pin	Signal
1	WAKE#	2	+3.3VSB
3	No use	4	GND
5	No use	6	+1.5V
7	CLKREQ#	8	No use
9	GND	10	No use
11	REFCLK-	12	No use
13	REFCLK+	14	No use
15	GND	16	No use
17	No use	18	GND
19	No use	20	W_DISABLE#
21	GND	22	PERST#
23	PE_RXN/ SATA_RXP	24	+3.3VSB
25	PE_RXP/ SATA_RXN	26	GND
27	GND	28	+1.5V
29	GND	30	SMB_CLK
31	PE_TXN3/ SATA_TXN	32	SMB_DATA
33	PE_TXP3/ SATA_TXP	34	GND
35	GND	36	USB_D8-
37	GND	38	USB_D8+
39	+3.3VSB	40	GND
41	+3.3VSB	42	No use
43	GND	44	No use
45	No use	46	No use
47	No use	48	+1.5V
49	No use	50	GND
51	No use	52	+3.3VSB



2.4.13 FAN Connectors (FAN1 and FAN2)

Fans are always needed for cooling down CPU and system temperature. The board has two fan connectors. You can find fan speed option(s) at BIOS Setup Utility if either fan is installed. For further information, see BIOS Setup Utility: Advanced\HW Monitor\PC Health Status.

CPU fan interface is available through FAN1, see table below.

Pin	Signal
1	GND
2	+12V level
3	Rotation detection
4	Speed control



System fan interface is available through FAN2, see table below.

Pin	Signal
1	GND
2	+12V level
3	Rotation detection



2.4.14 Front Panel Connector (JP6)

Pin	Signal
1	PWRLED+
2	EXT SPK-
3	GND
4	Buzzer
5	PWRLED-
6	N.C.
7	N.C.
8	EXT SPK+
9	PWRSW-
10	PWRSW+
11	HW RST-
12	HW RST+
13	HDDLED-
14	HDDLED+



Power LED

Pin 1 connects anode(+) of LED and pin 5 connects cathode(-) of LED. The power LED lights up when the system is powered on. The pin 3 is defined as GND.

External Speaker and Internal Buzzer

Pin 2, 4, 6 and 8 connect the case-mounted speaker unit or internal buzzer. While connecting the CPU board to an internal buzzer, please set pin 2 and 4 closed; while connecting to an external speaker, you need to set pins 2 and 4 opened and connect the speaker cable to pin 8(+) and pin 2(-).

Power On/Off Button
Pin 9 and 10 connect the power button on front panel to the CPU board, which allows users to turn on or off power supply.

System Reset Switch
Pin 11 and 12 connect the case-mounted reset switch that reboots your computer without turning off the power switch. It is a better way to reboot your system for a longer life of system power supply.

HDD Activity LED
This connection is linked to hard drive activity LED on the control panel. LED flashes when HDD is being accessed. Pin 13 and 14 connect the hard disk drive to the front panel HDD LED, pin 13 is assigned as cathode(-) and pin 14 is assigned as anode(+).

2.4.15 Digital I/O Connector (JP9)

The board is equipped with an 8-channel digital I/O connector that meets requirements for a system customary automation control. The digital I/O can be configured to control cash drawers and sense warning signals from an Uninterrupted Power System (UPS), or perform store security control. You may use software programming to control these digital signals.

Pin	Signal	Pin	Signal
1	DIO 8	2	DIO 1
3	DIO 7	4	DIO 2
5	DIO 6	6	DIO 3
7	DIO 5	8	DIO 4
9	GND	10	GND



This page is intentionally left blank.

Chapter 3
Hardware Installation

Before installing the processor, please access Intel® website for more detail information of Processor Integration Video (LGA1155)**:**

http://www.intel.com/support/tw/processors/sb/CS-030860.htm .

3.1 Installing the Processor

The LGA1155 processor socket comes with a cover to protect the processor. Please install the processor into the CPU socket step by step as below:

Step1 Opening the socket:

- Disengage load lever by releasing down and out on the hook. This will clear retention tab.
- Rotate load lever to open position at approximately 135°.
- Rotate load plate to open position at approximately 150°.

Note: ***Apply pressure to corner with right-hand thumb when opening or closing load lever - otherwise lever will bounce back (as a mouse trap) causing bent contacts.***

Step2 Removing the socket protective cover:

- Place thumb against the front edge of the protective cover and rest index finger on the rear grip to maintain control of the cover.
- Lift the front edge of the protective cover to disengage from the socket. Keep control of the cover by holding the rear grip with index finger.
- Lift protective cover away from the socket, being careful not to touch the electrical contacts.



Note: ***Vertical removal is NOT recommended, as it requires higher force and can lead to socket contact damage.***





Caution: ***Never touch fragile socket contacts to avoid damage and do not touch processor sensitive contacts at any time during installation.***

Step3 Processor installation:

- Lift processor package from shipping media by grasping the substrate edges.



- Scan the processor package gold pads for any presence of foreign material. If necessary, the gold pads can be wiped clean with a soft lint-free cloth and isopropyl alcohol.
- Locate connection 1 indicator on the processor which aligns with connection 1 indicator chamfer on the socket, and notice processor keying features that line up with posts along socket walls.





- Grasp the processor with thumb and index finger along the top and bottom edges. (Do not touch the orientation notches.) The socket will have cutouts for your fingers to fit into (see image below).
- Carefully place the processor into the socket body vertically (see image below).

Note: ***Tilting or roughly shifting it into place can damage socket contacts.***

Caution: ***Do not use a vacuum pen for installation.***



- Verify that package is within the socket body and properly connected to orientation keys.



- Close the socket (see image below):

1. Gently lower the load plate.
2. Make sure load plate's front edge slides under the shoulder screw cap as the lever is lowered.
3. Latch the lever under the top plate's corner tab, being cautious not to damage the motherboard with the tip of the lever.



Step4 Fan heatsink handling:

1. Orientate the CPU cooling fan to fixing holes on the board.



2. Screw the CPU cooling fan onto the board.



3. Make sure the CPU fan is plugged to the CPU fan connector.



Step5 Removing the processor:

- Open the socket:

  1. Disengage the load lever.
  2. Open the load plate

- Remove the Processor package, holding along the top and bottom edges, or by using a vacuum pen.
- Maintain Processor horizontal and remove Processor with a vertical motion to avoid damaging the socket contacts.



- Place the processor in a specially designed tray or ESD retainer for storage. Do not place directly on table resting on gold lands
- Assemble LGA1155 socket protective cover:

1. Hold protective cover at 45 degree angle to the LGA1155 Socket.
2. Carefully lower protective cover on hinge side first, to contact with the outside wall of the LGA1155 Socket:
3. Engage protective cover retention features to outside of LGA1155 Socket, AND align 2 cover corners to socket corners (This step is critical to avoid Bent Contact Damage!).
4. Lower protective cover to attach to the LGA1155 Socket on Shoulder screw side.

- Perform Visual and Tactile verification that protective cover is properly seated in the LGA1155 Socket:

  Hold cover and move gently “side by side” to feel the play within the cover and the LGA1155 Socket.



- Close the socket load plate and engage the load lever (see image below).

3.2 Installing the Memory

The board supports two 204-pin DDR3 SO-DIMM memory sockets with maximum memory capacity up to 16GB.

Note: ***A DDR3 module has the same physical dimensions as a DDR2 SO-DIMM but is notched differently to prevent installation on a DDR2 SO-DIMM socket.***

Please follow steps below to install the memory modules:

- Push down latches on each side of the SO-DIMM socket.
- Align the memory module with the socket that notches of memory module must match the socket keys for a correct installation.
- Install the memory module into the socket and push it firmly down until it is fully seated. The socket latches are levered upwards and clipped on to the edges of the SO-DIMM.
- Install any remaining SO-DIMM modules.

This page is intentionally left blank.

Chapter 4
Hardware Description

4.1 Microprocessors

The MANO871 Series supports Intel® Core™ i7 / Core™ i5 / Core™ i3 / Celeron® processors, which enable your system to operate under Windows® XP, Windows® 7 and Linux environments. The system performance depends on the microprocessor. Make sure all correct settings are arranged for your installed microprocessor to prevent the CPU from damages.

4.2 BIOS

The MANO871 Series uses AMI Plug and Play BIOS with a single 64Mbit SPI Flash.

4.3 System Memory

The MANO871 Series supports two 204-pin DDR3 SO-DIMM sockets for a maximum memory of 16GB DDR3 SDRAMs. The memory module comes in sizes of 1GB, 2GB and 4GB.

4.4 I/O Port Address Map

The Intel® Core™ i7 / Core™ i5 / Core™ i3 / Celeron® processors communicate via I/O ports. Total 1KB port addresses are available for assigning to other devices via I/O expansion cards.


Input/output (IO)
[00000000 - 0000001F] Direct memory access controller
[00000000 - 00000CF7] PCI bus
[00000010 - 0000001F] Motherboard resources
[00000020 - 00000021] Programmable interrupt controller
[00000022 - 0000003F] Motherboard resources
[00000024 - 00000025] Programmable interrupt controller
[00000028 - 00000029] Programmable interrupt controller
[0000002C - 0000002D] Programmable interrupt controller
[0000002E - 0000002F] Motherboard resources
[00000030 - 00000031] Programmable interrupt controller
[00000034 - 00000035] Programmable interrupt controller
[00000038 - 00000039] Programmable interrupt controller
[0000003C - 0000003D] Programmable interrupt controller
[00000040 - 00000043] System timer
[00000044 - 0000005F] Motherboard resources
[0000004E - 0000004F] Motherboard resources
[00000050 - 00000053] System timer
[00000061 - 00000061] Motherboard resources
[00000062 - 00000063] Motherboard resources
[00000063 - 00000063] Motherboard resources
[00000065 - 00000065] Motherboard resources
[00000065 - 0000006F] Motherboard resources
[00000067 - 00000067] Motherboard resources
[00000070 - 00000070] Motherboard resources
[00000070 - 00000077] System CMOS/real time clock
[00000072 - 0000007F] Motherboard resources
[00000080 - 00000080] Motherboard resources
[00000080 - 00000080] Motherboard resources
[00000081 - 00000091] Direct memory access controller
[00000084 - 00000086] Motherboard resources
[00000088 - 00000088] Motherboard resources
[0000008C - 0000008E] Motherboard resources
[00000090 - 0000009F] Motherboard resources
[00000092 - 00000092] Motherboard resources
[00000093 - 0000009F] Direct memory access controller
[000000A0 - 000000A1] Programmable interrupt controller
[000000A2 - 000000BF] Motherboard resources
[000000A4 - 000000A5] Programmable interrupt controller
[000000A8 - 000000A9] Programmable interrupt controller
[000000AC - 000000AD] Programmable interrupt controller
[000000B0 - 000000B1] Programmable interrupt controller
[000000B2 - 000000B3] Motherboard resources
[000000B4 - 000000B5] Programmable interrupt controller
[000000B8 - 000000B9] Programmable interrupt controller
[000000BC - 000000BD] Programmable interrupt controller
[000000C0 - 000000DF] Direct memory access controller
[000000E0 - 000000EF] Motherboard resources
[000000F0 - 000000FF] Numeric data processor
[00000200 - 0000020F] Motherboard resources
[00000274 - 00000277] ISAPNP Read Data Port
[00000279 - 00000279] ISAPNP Read Data Port
[00000290 - 00000297] Motherboard resources
[000002E8 - 000002EF] Communications Port (COM4)
[000002F8 - 000002FF] Communications Port (COM2)


[000003B0 - 000003BB] Intel(R) HD Graphics
[000003C0 - 000003DF] Intel(R) HD Graphics
[000003E8 - 000003EF] Communications Port (COM3)
[000003F8 - 000003FF] Communications Port (COM1)
[00000400 - 00000453] Motherboard resources
[00000454 - 00000457] Motherboard resources
[00000458 - 0000047F] Motherboard resources
[000004D0 - 000004D1] Motherboard resources
[000004D0 - 000004D1] Programmable interrupt controller
[00000500 - 0000057F] Motherboard resources
[00000680 - 0000069F] Motherboard resources
[00000A79 - 00000A79] ISAPNP Read Data Port
[00000D00 - 0000FFFF] PCI bus
[0000164E - 0000164F] Motherboard resources
[0000E000 - 0000E01F] Intel(R) 82583V Gigabit Network Connection
[0000E000 - 0000EFFF] Intel(R) 7 Series/C216 Chipset Family PCI Express Root Port 7 - 1E1C
[0000F000 - 0000F03F] Intel(R) HD Graphics
[0000F040 - 0000F05F] Intel(R) 7 Series/C216 Chipset Family SMBus Host Controller - 1E22
[0000F060 - 0000F07F] Intel(R) 82579LM Gigabit Network Connection
[0000F080 - 0000F08F] Intel(R) 7 Series/C216 Chipset Family 2 port Serial ATA Storage Controller - 1E08
[0000F090 - 0000F09F] Intel(R) 7 Series/C216 Chipset Family 2 port Serial ATA Storage Controller - 1E08
[0000F0A0 - 0000F0A3] Intel(R) 7 Series/C216 Chipset Family 2 port Serial ATA Storage Controller - 1E08
[0000F0B0 - 0000F0B7] Intel(R) 7 Series/C216 Chipset Family 2 port Serial ATA Storage Controller - 1E08
[0000F0C0 - 0000F0C3] Intel(R) 7 Series/C216 Chipset Family 2 port Serial ATA Storage Controller - 1E08
[0000F0D0 - 0000F0D7] Intel(R) 7 Series/C216 Chipset Family 2 port Serial ATA Storage Controller - 1E08
[0000F0E0 - 0000F0EF] Intel(R) 7 Series/C216 Chipset Family 4 port Serial ATA Storage Controller - 1E00
[0000F0F0 - 0000F0FF] Intel(R) 7 Series/C216 Chipset Family 4 port Serial ATA Storage Controller - 1E00
[0000F100 - 0000F103] Intel(R) 7 Series/C216 Chipset Family 4 port Serial ATA Storage Controller - 1E00
[0000F110 - 0000F117] Intel(R) 7 Series/C216 Chipset Family 4 port Serial ATA Storage Controller - 1E00
[0000F120 - 0000F123] Intel(R) 7 Series/C216 Chipset Family 4 port Serial ATA Storage Controller - 1E00
[0000F130 - 0000F137] Intel(R) 7 Series/C216 Chipset Family 4 port Serial ATA Storage Controller - 1E00
[0000F140 - 0000F147] Intel(R) Active Management Technology - SOL (COM5)
[0000FFFF - 0000FFFF] Motherboard resources
[0000FFFF - 0000FFFF] Motherboard resources

4.5 Interrupt Controller (IRQ) Map

The interrupt controller (IRQ) mapping list is shown as follows:


Interrupt request (IRQ)
(ISA) 0 System timer
(ISA) 3 Communications Port (COM2)
(ISA) 4 Communications Port (COM1)
(ISA) 7 Communications Port (COM3)
(ISA) 7 Communications Port (COM4)
(ISA) 8 System CMOS/real time clock
(ISA) 9 Microsoft ACPI-Compliant System
(ISA) 13 Numeric data processor
(PCI) 10 Intel(R) 7 Series/C216 Chipset Family SMBus Host Controller - 1E22
(PCI) 11 Intel(R) 7 Series/C216 Chipset Family Universal Serial Bus (USB) Controller - 1E31
(PCI) 16 Intel(R) 7 Series/C216 Chipset Family PCI Express Root Port 1 - 1E10
(PCI) 16 Intel(R) 7 Series/C216 Chipset Family USB Enhanced Host Controller - 1E2D
(PCI) 16 Intel(R) HD Graphics
(PCI) 16 Intel(R) Management Engine Interface
(PCI) 18 Intel(R) 7 Series/C216 Chipset Family PCI Express Root Port 7 - 1E1C
(PCI) 18 Intel(R) 82583V Gigabit Network Connection
(PCI) 19 Intel(R) 7 Series/C216 Chipset Family 2 port Serial ATA Storage Controller - 1E08
(PCI) 19 Intel(R) 7 Series/C216 Chipset Family 4 port Serial ATA Storage Controller - 1E00
(PCI) 19 Intel(R) Active Management Technology - SOL (COM5)
(PCI) 20 Intel(R) 82579LM Gigabit Network Connection
(PCI) 22 Microsoft UAA Bus Driver for High Definition Audio
(PCI) 23 Intel(R) 7 Series/C216 Chipset Family USB Enhanced Host Controller - 1E26

4.6 Memory Map

The memory mapping list is shown as follows:


Memory
[000A0000 - 000BFFFF] Intel(R) HD Graphics
[000A0000 - 000BFFFF] PCI bus
[000D0000 - 000D3FFF] PCI bus
[000D4000 - 000D7FFF] PCI bus
[000D8000 - 000DBFFF] PCI bus
[000DC000 - 000DFFFF] PCI bus
[000E0000 - 000E3FFF] PCI bus
[000E4000 - 000E7FFF] PCI bus
[20000000 - 201FFFFF] System board
[40004000 - 40004FFF] System board
[BFA00000 - BFA00FFF] Motherboard resources
[BFA00000 - FEAFFFFF] PCI bus
[E0000000 - EFFFFFFF] Intel(R) HD Graphics
[F7800000 - F7BFFFFF] Intel(R) HD Graphics
[F7C00000 - F7C1FFFF] Intel(R) 82583V Gigabit Network Connection
[F7C00000 - F7CFFFFF] Intel(R) 7 Series/C216 Chipset Family PCI Express Root Port 7 - 1E1C
[F7C20000 - F7C23FFF] Intel(R) 82583V Gigabit Network Connection
[F7D00000 - F7D1FFFF] Intel(R) 82579LM Gigabit Network Connection
[F7D20000 - F7D2FFFF] Intel(R) 7 Series/C216 Chipset Family Universal Serial Bus (USB) Controller - 1E31
[F7D30000 - F7D33FFF] Microsoft UAA Bus Driver for High Definition Audio
[F7D35000 - F7D350FF] Intel(R) 7 Series/C216 Chipset Family SMBus Host Controller - 1E22
[F7D36000 - F7D363FF] Intel(R) 7 Series/C216 Chipset Family USB Enhanced Host Controller - 1E26
[F7D37000 - F7D373FF] Intel(R) 7 Series/C216 Chipset Family USB Enhanced Host Controller - 1E2D
[F7D38000 - F7D38FFF] Intel(R) 82579LM Gigabit Network Connection
[F7D39000 - F7D39FFF] Intel(R) Active Management Technology - SOL (COM5)
[F7D3B000 - F7D3B00F] Intel(R) Management Engine Interface
[F8000000 - FBFFFFFF] Motherboard resources
[FED00000 - FED003FF] High precision event timer
[FED10000 - FED17FFF] Motherboard resources
[FED18000 - FED18FFF] Motherboard resources
[FED19000 - FED19FFF] Motherboard resources
[FED1C000 - FED1FFFF] Motherboard resources
[FED20000 - FED3FFFF] Motherboard resources
[FED40000 - FED44FFF] System board
[FED45000 - FED8FFFF] Motherboard resources
[FED90000 - FED93FFF] Motherboard resources
[FEE00000 - FEEFFFFF] Motherboard resources
[FF000000 - FFFFFFFF] Intel(R) 82802 Firmware Hub Device
[FF000000 - FFFFFFFF] Motherboard resources

This page is intentionally left blank.

Chapter 5
AMI BIOS Setup Utility

The AMI UEFI BIOS provides users with a built-in setup program to modify basic system configuration. All configured parameters are stored in a flash chip to save the setup information whenever the power is turned off. This chapter provides users with detailed description about how to set up basic system configuration through the AMI BIOS setup utility.

5.1 Starting

To enter the setup screens, follow the steps below:

1. Turn on the computer and press the <Del> key immediately.
2. After you press the <Del> key, the main BIOS setup menu displays. You can access the other setup screens from the main BIOS setup menu, such as the Advanced and Chipset menus.

Note: ***If your computer can not boot after making and saving system changes with Setup, you can restore BIOS optimal defaults by setting JP1 (see section 2.3.1) .***

It is strongly recommended that you should avoid changing the chipset's defaults. Both AMI and your system manufacturer have carefully set up these defaults that provide the best performance and reliability.

5.2 Navigation Keys

The BIOS setup/utility uses a key-based navigation system called hot keys. Most of the BIOS setup utility hot keys can be used at any time during the setup navigation process. These keys include <F1>, <F2>, <Enter>, <ESC>, <Arrow> keys, and so on.

Note: ***Some of the navigation keys differ from one screen to another.***

Hot Keys	Description
→← **Left/Right**	The Left and Right <Arrow> keys allow you to select a setup screen.
↑↓ **Up/Down**	The Up and Down <Arrow> keys allow you to select a setup screen or sub-screen.
+– Plus/Minus	The Plus and Minus <Arrow> keys allow you to change the field value of a particular setup item.
Tab	The <Tab> key allows you to select setup fields.
F1	The <F1> key allows you to display the General Help screen.
F2	The <F2> key allows you to Load Previous Values.
F3	The <F3> key allows you to Load Optimized Defaults.
F4	The <F4> key allows you to save any changes you have made and exit Setup. Press the <F4> key to save your changes.
Esc	The <Esc> key allows you to discard any changes you have made and exit the Setup. Press the <Esc> key to exit the setup without saving your changes.
Enter	The <Enter> key allows you to display or change the setup option listed for a particular setup item. The <Enter> key can also allow you to display the setup sub- screens.

5.3 Main Menu

When you first enter the setup utility, you will enter the Main setup screen. You can always return to the Main setup screen by selecting the Main tab. System Time/Date can be set up as described below. The Main BIOS setup screen is shown below.



System Date/Time
Use this option to change the system time and date. Highlight System Time or System Date using the <Arrow> keys. Enter new values through the keyboard. Press the <Tab> key or the <Arrow> keys to move between fields. The date must be entered in MM/DD/YY format. The time is entered in HH:MM:SS format.

5.4 Advanced Menu

The Advanced menu also allows users to set configuration of the CPU and other system devices. You can select any of the items in the left frame of the screen to go to the sub menus:

- ▶ ACPI Settings
- ▶ Trusted Computing
- ▶ CPU Configuration
- ▶ SATA Configuration
- ▶ PCH-FW Configuration
- ▶ AMT Configuration
- ▶ USB Configuration
- ▶ NCT6627UD Super IO Configuration
- ▶ NCT6627UD HW Monitor

For items marked with "▶", please press <Enter> for more options.



- **ACPI Settings**
  You can use this screen to select options for the ACPI configuration, and change the value of the selected option. A description of the selected item appears on the right side of the screen.

Aptio Setup Utility - Copyright (C) 2012 American Megatrends, Inc.
Advanced
ACPI Settings
ACPI Sleep State
[S3 only(Suspend to ...]
Select ACPI sleep state the system will enter when the SUSPEND button is pressed.
→←: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit
Version 2.15.1226. Copyright (C) 2012 American Megatrends, Inc.

ACPI Sleep State
Select the highest ACPI sleep state the system will enter when the suspend button is pressed. Configuration options are Suspend Disabled, S1 only (CPU Stop Clock), and S3 only (Suspend to RAM).

To correctly support wake by use of USB from the S3 system power state, please refer to the following Microsoft's link:

http://support.microsoft.com/kb/841858/en-us

- **Trusted Computing**
  This screen provides function for specifying the TPM settings.


Aptio Setup Utility - Copyright (C) 2012 American Megatrends, Inc.
Advanced
Configuration
Security Device Support [Disable]
Current Status Information
SUPPORT TURNED OFF
Enables or Disables BIOS support for security device. O.S. will not show Security Device. TCG EFI protocol and INT1A interface will not be available.
→←: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit
Version 2.15.1226. Copyright (C) 2012 American Megatrends, Inc.

Security Device Support
Use this item to enable or disable BIOS support for security device.

Current Status Information
Display current TPM status information.

- **CPU Configuration**
  This screen shows the CPU information.



EIST
Enable or disable Intel® SpeedStep. When enabled, CPU speed is controlled by the operating system. When disabled, CPU runs at its default speed.

Turbo Mode
This item is for enabling or disabling turbo mode. When enabled, it allows processor cores to run faster than marked frequency under certain conditions.

Intel Virtualization Technology
This item allows a hardware platform to run multiple operating systems separately and simultaneously, enabling one system to virtually function as several systems.

Hyper-threading
Use this item to enable or disable Hyper-Threading Technology, which makes a single physical processor perform multi-tasking function as two logical ones.

- **SATA Configuration**
  In this Configuration menu, you can see the currently installed hardware in the SATA ports. During system boot up, the BIOS automatically detects the presence of SATA devices.


Aptio Setup Utility - Copyright (C) 2012 American Megatrends, Inc.
Advanced
SATA Controller(s) [Enabled]
SATA Mode Selection [IDE]
Serial ATA Port 0 INTEL SSDSC2MH (120.0GB)
Software Preserve SUPPORTED
Serial ATA Port 1 Empty
Software Preserve Unknown
Serial ATA Port 2 ASUS DRW-24 ATAPI
Software Preserve N/A
Serial ATA Port 3 Empty
Software Preserve Unknown
Enable or disable SATA Device.
→←: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit
Version 2.15.1226. Copyright (C) 2012 American Megatrends, Inc.

SATA Controller(s)
Enable or disable SATA device.

SATA Mode Selection
Determine how SATA controller(s) operate. Operation mode options are: IDE Mode, AHCI Mode and RAID Mode.

- **PCH-FW Configuration**
  This screen displays Management Engine (ME) Firmware information.



- **AMT Configuration**
  Use this screen to configure AMT parameters.


Aptio Setup Utility - Copyright (C) 2012 American Megatrends, Inc.
Advanced
Intel AMT
[Enabled]
Disable ME
[Disabled]
Enable/Disable Intel (R) Active Management Technology BIOS Extension.
Note : iAMT H/W is always enabled.
This option just controls the BIOS extension execution.
If enabled, this requires additional firmware in the SPI device.
→←: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit
Version 2.15.1226. Copyright (C) 2012 American Megatrends, Inc.

Intel AMT
Enable or disable Intel® Active Management Technology BIOS Extension.

Disable ME
Enable or disable ME functionality.

- **USB Configuration**
  You can use this screen to select options for the USB Configuration, and change the value of the selected option. A description of the selected item appears on the right side of the screen.


Aptio Setup Utility - Copyright (C) 2012 American Megatrends, Inc.
Advanced
USB Configuration
USB Devices:
1 Keyboard, 1 Mouse, 2 Hubs
Legacy USB Support [Enabled]
Enables Legacy USB support. AUTO option disables legacy support if no USB devices are connected. DISABLE option will keep USB devices available only for EFI applications.
→←: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit
Version 2.15.1226. Copyright (C) 2012 American Megatrends, Inc.

USB Devices
Display all detected USB devices.

Legacy USB Support
Use this item to enable or disable support for USB device on legacy operating system. The default setting is Enabled. Auto option disables legacy support if no USB devices are connected. Disable option will keep USB devices available only for EFI applications.

- **NCT6627UD Super IO Configuration**
  You can use this screen to select options for the Super IO Configuration, and change the value of the selected option. A description of the selected item appears on the right side of the screen. For items marked with "►", please press <Enter> for more options.


Aptio Setup Utility - Copyright (C) 2012 American Megatrends, Inc.
Advanced
NCT6627UD Super IO Configuration
NCT6627UD Super IO Chip NCT6627UD
► Serial Port 1 Configuration
► Serial Port 2 Configuration
► Serial Port 3 Configuration
► Serial Port 4 Configuration
Set Parameters of Serial Port 1 (COMA)
→←: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit
Version 2.15.1226. Copyright (C) 2012 American Megatrends, Inc.

Serial Port 1~4 Configuration
Use this item to set parameters of serial port 1 to 4.

- **NCT6627UD HW Monitor**
  Use this screen for Smart Fan configuration and hardware health status monitoring.


Aptio Setup Utility - Copyright (C) 2012 American Megatrends, Inc.
Advanced
Pc Health Status
Smart Fan Function [Disabled]
SYS Thermistor Temp : +35 C
CPU PECI Temp : +34.25 C
SysFan Speed : N/A
CpuFan Speed : 4326 RPM
VCORE : +0.904 V
+12V : +12.032 V
+3.3V : +3.392 V
+5V : +5.024 V
Enable or Disable Smart Fan
→←: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit
Version 2.15.1226. Copyright (C) 2012 American Megatrends, Inc.

This screen displays the temperature of system and CPU, cooling fan speed in RPM and system voltages (VCORE, +12V, +3.3V and +5V).

Smart Fan Function
Enable or disable Smart Fan function.

5.5 Chipset Menu

The Chipset menu allows users to change the advanced chipset settings. You can select any of the items in the left frame of the screen to go to the sub menus:

- ► PCH-IO Configuration
- ► System Agent (SA) Configuration

For items marked with "►", please press <Enter> for more options.



- **PCH-IO Configuration**
  This screen allows you to set PCH parameters.


Aptio Setup Utility - Copyright (C) 2012 American Megatrends, Inc.
Main Advanced Chipset Boot Security Save & Exit
Intel PCH RC Version Q77
USB Configuration
PCH Azalia Configuration
Launch PXE OpROM policy [Do not Launch]
PCH LAN Controller [Enabled]
Wake on LAN [Enabled]
USB Configuration settings.
→←: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit
Version 2.15.1226. Copyright (C) 2012 American Megatrends, Inc.

USB Configuration
Use this item for USB configuration settings.

PCH Azalia Configuration
Use this item for PCH Azalia configuration settings.

Launch PXE OpROM policy
Control the execution of UEFI and Legacy PXE OpROM.

PCH LAN Controller
Enable or disable PCH LAN controller.

Wake on LAN
Enable or disable Wake on LAN functionality.

- **System Agent (SA) Configuration**
  This screen shows System Agent information and provides function for specifying related parameters. For items marked with "►", please press <Enter> for more options.



VT-d
Enable or disable Intel® chipset virtualization technology for directed I/O. VT-d can help end users improve security and reliability of the systems and also improve performance of I/O devices in virtualized environment.

Graphics Configuration
Use this item for graphics configuration settings.

Memory Configuration
Use this item for memory configuration settings.

- **Graphics Configuration**


Aptio Setup Utility – Copyright (C) 2012 American Megatrends, Inc.
Chipset
Graphics Configuration
Primary Display [Auto]
Primary IGFX Boot Display [CRT]
Secondary IGFX Boot Display [HDMI]
LVDS Panel Type [800x600 18Bit]
LVDS Brightness [70%]
DVMT Pre-Allocated [64M]
DVMT Total Gfx Mem [256M]
Select which of IGFX/PEG/PCI Graphics device should be Primary Display Or select SG for Switchable Gfx.
→←: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit
Version 2.15.1226. Copyright (C) 2012 American Megatrends, Inc.

Primary Display
Allow you to select which graphics controller to use as the primary boot device.

Primary IGFX Boot Display
Allow you to select the display device which will be activated during POST. This has no effect if external graphics present. Secondary boot display selection will appear based on your selection. Primary IGFX boot display options are: CRT, DVI, LVDS and HDMI.

Secondary IGFX Boot Display
Use this item to select secondary display device. Secondary IGFX boot display options are: CRT, DVI, LVDS and HDMI.

LVDS Panel Type
Use this item to select LVDS panel used by internal graphics controller by selecting the appropriate setup item.

LVDS Brightness
Select LVDS brightness that ranges from 30% to 100%. The default setting is 70%.

DVMT Pre-Allocated
Select DVMT pre-allocated memory size.

DVMT Total Gfx Mem
Select DVMT total memory size.

5.6 Boot Menu

The Boot menu allows users to change boot options of the system.



- **Setup Prompt Timeout**
  Number of seconds to wait for setup activation key. 65535(0xFFFF) means indefinite waiting.

- **Bootup NumLock State**
  Use this item to select the power-on state for the keyboard NumLock.

- **Quiet Boot**
  Select to display either POST output messages or a splash screen during boot-up.

- **Fast Boot**
  Enable or disable boot with initialization of minimal set of devices required to launch active boot option. Has no effect for BBS boot options.

- **Boot Option Priorities**
  These are settings for boot priority. Specify the boot device priority sequence from the available devices.

- **Boot Option #1..#2**
  These items are used to form the boot order and are dynamically generated. They represent either a legacy BBS (BIOS Boot Specification) class of devices or a native EFI boot entry. Press <Return> on each option to select the BBS class / EFI boot entry desired.

- **CD/DVD ROM Drive BBS/Hard Drive BBS Priorities**
  These items are for configuring the boot order for a specific device class. These options are only visible if at least one device for this class is detected.

5.7 Security Menu

The Security menu allows users to change the security settings for the system.


Aptio Setup Utility - Copyright (C) 2012 American Megatrends, Inc.
Main Advanced Chipset Boot Security Save & Exit
Password Description
If ONLY the Administrator's password is set, then this only limits access to Setup and is only asked for when entering Setup.
If ONLY the User's password is set, then this is a power on password and must be entered to boot or enter Setup. In Setup the User will have Administrator rights.
The password length must be in the following range:
Minimum length 3
Maximum length 20
Administrator Password
User Password
Set Administrator Password
→←: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit
Version 2.15.1226. Copyright (C) 2012 American Megatrends, Inc.

- **Administrator Password**
  This item indicates whether an administrator password has been set (installed or uninstalled).

- **User Password**
  This item indicates whether an user password has been set (installed or uninstalled).

5.8 Save & Exit Menu

The Save & Exit menu allows users to load your system configuration with optimal or fail-safe default values.



- **Save Changes and Exit**
  When you have completed the system configuration changes, select this option to leave Setup and return to Main Menu. Select Save Changes and Exit from the Save & Exit menu and press <Enter>. Select Yes to save changes and exit.

- **Discard Changes and Exit**
  Select this option to quit Setup without making any permanent changes to the system configuration and return to Main Menu. Select Discard Changes and Exit from the Save & Exit menu and press <Enter>. Select Yes to discard changes and exit.

- **Save Changes and Reset**
  When you have completed the system configuration changes, select this option to leave Setup and reboot the computer so the new system configuration parameters can take effect. Select Save Changes and Reset from the Save & Exit menu and press <Enter>. Select Yes to save changes and reset.

- **Discard Changes and Reset**
  Select this option to quit Setup without making any permanent changes to the system configuration and reboot the computer. Select Discard Changes and Reset from the Save & Exit menu and press <Enter>. Select Yes to discard changes and reset.

- **Save Changes**
  When you have completed the system configuration changes, select this option to save changes. Select Save Changes from the Save & Exit menu and press <Enter>. Select Yes to save changes.

- **Discard Changes**
  Select this option to quit Setup without making any permanent changes to the system configuration. Select Discard Changes from the Save & Exit menu and press <Enter>. Select Yes to discard changes.

- **Restore Defaults**
  It automatically sets all Setup options to a complete set of default settings when you select this option. Select Restore Defaults from the Save & Exit menu and press <Enter>.

- **Save as User Defaults**
  Select this option to save system configuration changes done so far as User Defaults. Select Save as User Defaults from the Save & Exit menu and press <Enter>.

- **Restore User Defaults**
  It automatically sets all Setup options to a complete set of User Defaults when you select this option. Select Restore User Defaults from the Save & Exit menu and press <Enter>.

- **Launch EFI Shell from filesystem device**
  Attempt to launch EFI Shell application (Shellx64.efi) from one of the available filesystem devices.

This page is intentionally left blank.

Appendix A
Watchdog Timer

About Watchdog Timer

After the system stops working for a while, it can be auto-reset by the watchdog timer. The integrated watchdog timer can be set up in the system reset mode by program.

How to Use Watchdog Timer

Start
↓
Un-Lock WDT:
O 2E 87 ; Un-lock super I/O
O 2E 87 ; Un-lock super I/O
↓
Select Logic device:
O 2E 07
O 2F 08
↓
Activate WDT:
O 2E 30
O 2F 01
↓
Set Second or Minute:
O 2E F5
O 2F N ; N=00 or 08 (See *Note* below)
↓
Set base timer:
O 2E F6
O 2F M ; M=00,01,02,…FF(Hex) ,Value=0 to 255
↓
WDT counting re-set timer:
O 2E F6
O 2F M ; M=00,01,02,…FF

;IF to disable WDT:
O 2E 30
O 2F 00 ; Can be disabled at any time

- Timeout Value Range
  - 1 to 255
  - Minute / Second

- Program Example

2E, 87	
2E, 87	
2E, 07	
2F, 08	Logical Device 8
2E, 30	Activate
2F, 01	
2E, F5	
2F, N	Set Minute or Second; N=08 (Min), 00(Sec)
2E, F6	
2F, M	Set Value; M=00~FF

Note:

*If **N**=00h, the time base is set to second.*
***M** = time value*
00h: Time-out Disable
01h: Time-out occurs after 1 second
02h: Time-out occurs after 2 seconds
03h: Time-out occurs after 3 seconds
.
.
FFh: Time-out occurs after 255 seconds

*If **N**=08h, the time base is set to minute.*
***M** = time value*
00h: Time-out Disable
01h: Time-out occurs after 1 minute
02h: Time-out occurs after 2 minutes
03h: Time-out occurs after 3 minutes
.
.
FFh: Time-out occurs after 255 minutes

Appendix B
Digital I/O

Using Digital Output Function

O 2E 87

O 2E 87

O 2E 07

O 2F 08

O 2E 30

O 2F 02 Setting DIO is active

O 2E E0

O 2F **00** **00**: The respective DIO is programmed as an output port

O 2E E1

O 2F **NN** **NN**: Setting output value

Note:
NN*=01 means output value is "00000001", DIO1 is output high, the rest DIO2~DIO8 are output low.*

Using Digital Input Function

O 2E 87

O 2E 87

O 2E 07

O 2F 08

O 2E 30

O 2F 02 Setting DIO is active

O 2E E0

O 2F **FF** **FF**: The respective DIO is programmed as an input port

O 2E E1

I 2F Read Input value

This page is intentionally left blank.

Appendix C
Configuring SATA for RAID

Configuring SATA Hard Drive(s) for RAID Function

Before you begin the SATA configuration, please prepare:

- Two SATA hard drives (to ensure optimal performance, it is recommended that you use two hard drives with identical model and capacity). If you do not want to create RAID with the SATA controller, you may prepare only one hard drive.
- An empty formatted floppy disk.
- Windows XP setup disk.

Please follow up the steps below to configure SATA hard drive(s):

1. Install SATA hard drive(s) in your system.
2. Enter the BIOS Setup to configure SATA controller mode and boot sequence.
3. Configure RAID by the RAID BIOS.
4. Making a SATA driver disk.
5. Install the SATA controller driver during the OS installation.

1. Installing SATA hard drive(s) in your system.

Connect one end of the SATA signal cable to the rear of the SATA hard drive, and the other end to available SATA port(s) on the board. Then, connect the power connector of power supply to the hard drive.

2. Configuring SATA controller mode and boot sequence by the BIOS Setup.

You have to make sure whether the SATA controller is configured correctly by system BIOS Setup and set up BIOS boot sequence for the SATA hard drive(s).

2.1. Turn on your system, and then press the <Del> button to enter BIOS Setup during running POST (Power-On Self Test). If you want to create RAID, just go to the Advanced Settings menu, select the “SATA Mode Selection”, and press <Enter> for more options. A list of options appears, please select “RAID”.


Aptio Setup Utility - Copyright (C) 2012 American Megatrends, Inc.
Advanced
SATA Controller(s) [Enabled]
SATA Mode Selection [RAID]
Serial ATA Port 0 WDC WD5000AAKX
Software Preserve en-US
Serial ATA Port 1 WDC WD5000AAKX
Software Preserve en-US
Serial ATA Port 2 Empty
Software Preserve Unknown
Serial ATA Port 3 ASUS DRW-24
Software Preserve en-US
Determines how SATA controller(s) operate.
→←: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit
Version 2.15.1226. Copyright (C) 2012 American Megatrends, Inc.

2.2. Set DVD-ROM for First Boot Option under the Boot Settings menu to boot DVD-ROM after system restarts.


Aptio Setup Utility - Copyright (C) 2012 American Megatrends, Inc.
Main Advanced Chipset Boot Security Save & Exit
Boot Configuration
Setup Prompt Timeout 1
Bootup Numlock State [On]
Quiet Boot [Disabled]
Fast Boot [Disabled]
Driver Option Priorities
Boot Option Priorities
Boot Option #1 [P3: ASUS DRW-24...]
Boot Option #2 [WDC WD5000AAKX]
Boot Option #3 [WDC WD5000AAKX]
CD/DVD ROM Drive BBS Priorities
Hard Drive BBS Priorities
Number of seconds to wait for setup activation key. 65535(0xFFFF) means indefinite waiting.
→←: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit
Version 2.15.1226. Copyright (C) 2012 American Megatrends, Inc.

2.3. Save and exit the BIOS Setup.

3. Configuring RAID by the RAID BIOS.

Enter the RAID BIOS setup utility to configure a RAID array. Skip this step and proceed if you do not want to create a RAID.

3.1. After the POST memory testing and before the operating system booting, a message "Press <Ctrl-I> to enter Configuration Utility" shows up, accordingly, press <Ctrl + I> to enter the RAID BIOS setup utility.


Intel(R) Rapid Storage Technology - Option ROM - 11.0.0.1339
Copyright(C) 2003-11 Intel Corporation. All Rights Reserved.
RAID Volumes:
ID Name Level Strip Size Status Bootable
0 Volume0 RAID0(Stripe) 128KB 465.8GB Normal Yes
Physical Devices:
ID Device Model Serial # Size Type/Status(Vol ID)
0 WDC WD5000AAKX-0 WD-WCAYUCM26947 465.7GB Member Disk(0)
1 WDC WD5000AAKX-0 WD-WMAYUF937005 465.7GB Member Disk(0)
Press <CTRL-I> to enter Configuration Utility...

3.2. After you press <Ctrl + I>, the Create RAID Volume screen will appear. If you want to create a RAID array, select the Create RAID Volume option in the Main Menu and press <Enter>.


Intel(R) Rapid Storage Technology - Option ROM - 11.0.0.1339
Copyright(C) 2003-11 Intel Corporation. All Rights Reserved.
[MAIN MENU]
1. Create RAID Volume
2. Delete RAID Volume
3. Reset Disks to Non-RAID
4. Recovery Volume Options
5. Acceleration Options
6. Exit
[DISK/VOLUME INFORMATION]
RAID Volumes:
None Defined.
Physical Devices:
ID Device Model Serial # Size Type/Status(Vol ID)
0 WDC WD5000AAKX-0 WD-WCAYUCM26947 465.7GB Non-RAID Disk
1 WDC WD5000AAKX-0 WD-WMAYUF937005 465.7GB Non-RAID Disk
[↑↓]-Select [ESC]-Exit [Enter]-Select Menu

3.3. After entering the Create Volume Menu screen, you can type the disk array name with 1~16 letters (letters cannot be special characters) in the item “Name”.


Intel(R) Rapid Storage Technology - Option ROM - 11.0.0.1339
Copyright(C) 2003-11 Intel Corporation. All Rights Reserved.
[CREATE VOLUME MENU]
Name: Volume0
RAID Level: RAID0 (Stripe)
Disks: Select Disks
Strip Size: 128KB
Capacity: 931.5 GB
Sync: N/A
Create Volume
[HELP]
Enter a unique volume name that has no special characters and is 16 characters or less.
[↓↑]Change [TAB]-Next [ESC]-Previous Menu [ENTER]-Select

3.4. When finished, press <Enter> to select a RAID level. There are three RAID levels: RAID0, RAID1 and RAID5 & RAID10. Select a RAID level and press <Enter>.


Intel(R) Rapid Storage Technology - Option ROM - 11.0.0.1339
Copyright(C) 2003-11 Intel Corporation. All Rights Reserved.
[CREATE VOLUME MENU]
Name: Volume0
RAID Level: RAID0(Stripe)
Disks: Select Disks
Strip Size: 128KB
Capacity: 931.5 GB
Sync: N/A
Create Volume
[HELP]
RAID 0: Stripes data (performance).
[↓↑]Change [TAB]-Next [ESC]-Previous Menu [ENTER]-Select

3.5. Set the stripe block size. The KB is the standard unit of stripe block size. The stripe block size can be 4KB to 128KB. After the setting, press <Enter> for the array capacity.



3.6. After setting all the items on the menu, select Create Volume and press <Enter> to start creating the RAID array.


Intel(R) Rapid Storage Technology - Option ROM - 11.0.0.1339
Copyright(C) 2003-11 Intel Corporation. All Rights Reserved.
[CREATE VOLUME MENU]
Name: Volume0
RAID Level: RAID0(Stripe)
Disks: Select Disks
Strip Size: 128KB
Capacity: 931.5 GB
Sync: N/A
Create Volume
[HELP]
The default value indicates the maximum capacity using the selected disks. Entering a lower capacity allows you to create a second volume on these disks.
[↓↑]Change [TAB]-Next [ESC]-Previous Menu [ENTER]-Select

3.7. When prompting the confirmation, press <Y> to create this volume, or <N> to cancel the creation.


Intel(R) Rapid Storage Technology - Option ROM - 11.0.0.1339
Copyright(C) 2003-11 Intel Corporation. All Rights Reserved.
[CREATE VOLUME MENU]
Name: Volume0
RAID Level: RAID0(Stripe)
Disks: Select Disks
Strip Size: 128KB
Capacity: 200 GB
Sync: N/A
WARNING: ALL DATA ON SELECTED DISKS WILL BE LOST.
Are you sure you want to create this volume? (Y/N):
Press ENTER to create the specified volume.
[↓↑]Change [TAB]-Next [ESC]-Previous Menu [ENTER]-Select

After the creation is completed, you can see detailed information about the RAID Array in the Disk/Volume Information section, including RAID mode, disk block size, disk name, and disk capacity, etc.


Intel(R) Rapid Storage Technology - Option ROM - 11.0.0.1339
Copyright(C) 2003-11 Intel Corporation. All Rights Reserved.
[MAIN MENU]
1. Create RAID Volume
2. Delete RAID Volume
3. Reset Disks to Non-RAID
4. Recovery Volume Options
5. Acceleration Options
6. Exit
[DISK/VOLUME INFORMATION]
RAID Volumes:
ID Name Level Strip Size Status Bootable
0 Volume0 RAID0(Stripe) 128KB 200.0GB Normal Yes
Physical Devices:
ID Device Model Serial # Size Type/Status(Vol ID)
0 WDC WD5000AAKX-0 WD-WCAYUCM26947 465.7GB Member Disk(0)
1 WDC WD5000AAKX-0 WD-WMAYUF937005 465.7GB Member Disk(0)
[↑↓]-Select [ESC]-Exit [Enter]-Select Menu

Delete RAID volume

If you want to delete a RAID volume, select the Delete RAID Volume option in Main Menu. Press <Enter> and follow on-screen instructions.


Intel(R) Rapid Storage Technology - Option ROM - 11.0.0.1339
Copyright(C) 2003-11 Intel Corporation. All Rights Reserved.
[MAIN MENU]
1. Create RAID Volume
2. Delete RAID Volume
3. Reset Disks to Non-RAID
4. Recovery Volume Options
5. Acceleration Options
6. Exit
[DISK/VOLUME INFORMATION]
RAID Volumes:
ID Name Level Strip Size Status Bootable
0 Volume0 RAID0(Stripe) 128KB 200.0GB Normal Yes
Physical Devices:
ID Device Model Serial # Size Type/Status(Vol ID)
0 WDC WD5000AAKX-0 WD-WCAYUCM26947 465.7GB Member Disk(0)
1 WDC WD5000AAKX-0 WD-WMAYUF937005 465.7GB Member Disk(0)
[↑↓]-Select
[ESC]-Exit
[Enter]-Select Menu

Please press <Esc> to exit the RAID BIOS utility. Now, you can proceed to install a SATA driver controller and the operating system.

4. Making a SATA driver disk.

To install the operating system onto a serial ATA hard disk successfully, you need to install the SATA controller driver during the OS installation. Without the driver, the hard disk may not be recognized during the Windows setup process. First of all, please format a blank floppy disk. Secondly, follow up these steps below to produce a SATA driver disk.

Users can insert the driver DVD and the formatted blank floppy disk in another system. And then, please copy all of file of the “f6flpy-x32” folder in the driver DVD to a floppy disk.

Note: ***Please copy all of file of the “f6flpy-x64” folder, if installing 64-bit Windows Operating System.***

5. Installing the SATA controller driver during the OS installation

Now, the SATA driver disk is ready, and BIOS settings configured, you can proceed to install Windows 2000/XP onto your SATA hard drive using the SATA driver. Here is an example for Windows XP installation.

5.1. Restart your system to boot the Windows 2000/XP Setup disk, and press <F6> button as soon as you see the message "Press F6 if you need to install a 3rd party SCSI or RAID driver". After pressing the <F6> button, there will be a few moments for some files being loaded before next screen appears.

5.2. When you see the screen below, insert the floppy disk containing the SATA driver and press <S>.

Windows Setup
Setup could not determine the type of one or more mass storage devices
Installed in your system, or you have chosen to manually specify an adapter.
Currently, Setup will load support for the following mass storage devices(s):
<none>
* To specify additional SCSI adapters, CD-ROM drives, or special disk controllers for use with Windows, including those for which you have a device support disk from a mass storage device manufacturer, press S.
* If you do not have any device support disks from a mass storage device manufacturer, or do not want to specify additional mass storage devices for use with Windows, press ENTER.
S = Specify Additional Device ENTER = Continue F3 = Exit

5.3. If the Setup correctly recognizes the driver of the floppy disk, a controller menu will appear below. Use the <Arrow> keys to select "Intel(R) Desktop/Workstation/Server Express Chipset SATA RAID Controller" and press <Enter>**.** Then it will begin to load the SATA driver from the floppy disk.


Windows Setup
You have chosen to configure a SCSI Adapter for use with Windows, using a device support disk provided by an adapter manufacturer.
Select the SCSI Adapter you want from the following list, or press ESC to return to the previous screen.
Intel(R) ICH7R/DH SATA RAID controller
Intel(R) ICH7MDH SATA RAID controller
Intel(R) Desktop/Workstation/Server Express Chipset SATA RAID Controller
Intel(R) Mobile Express Chipset SATA RAID controller
ENTER = Select F3 = Exit

Note: ***If a message on the screen saying that one or some file(s) cannot be found, please check the floppy disk or copy the correct SATA driver again from the driver DVD.***


Windows Setup
You have chosen to configure a SCSI Adapter for use with Windows, using a device support disk provided by an adapter manufacturer.
Select the SCSI Adapter you want from the following list, or press ESC to return to the previous screen.
Intel(R) 7 Series/C216 Chipset Family SATA AHCI Controller
Intel(R) 7 Series Chipset Family SATA AHCI Controller
Intel(R) ICH7R/DH SATA RAID controller
Intel(R) ICH7MDH SATA RAID Controller
ENTER = Select F3 = Exit

Note: ***If you are installing AHCI, please select "Intel 7 Series/C216 Chipset Family SATA AHCI Controller".***

This page is intentionally left blank.

Appendix D
Intel® iAMT Settings

The Intel® Active Management Technology (Intel® iAMT) has decreased a major barrier to IT efficiency that uses built-in platform capabilities and popular third-party management and security applications to allow IT a better discovering, healing, and protection their networked computing assets.

In order to utilize Intel® iAMT you must enter the ME BIOS (<Ctrl + P> during system startup), change the ME BIOS password, and then select "Intel® iAMT" as the manageability feature.

Entering MEBx

1. You must go to BIOS to enable Intel® iAMT function.
2. Exit from BIOS after starting Intel® iAMT, and press <Ctrl + P> to enter MEBx Setting.

Note: ***It is better to press <Ctrl + P> before the screen popping out.***

American Megatrends
Version 2.15.1226. Copyright (C) 2012 American Megatrends, Inc.
BIOS Date: 02/10/2012 16:40:56 Ver: 1APTC
Press <CTRL + P> to Enter MEBX setup menu
Press <DEL> or <F2> to enter setup.

Set and Change Password

1. You will be asked to set a password when first log in. The default password is “admin”.


Intel(R) Management Engine BIOS Extension v8.0.0.0061/Intel(R) ME v8.1.0.1265
Copyright(C) 2003-12 Intel Corporation. All Rights Reserved.
MAIN MENU
MEBx Login
> Intel(R) ME General Settings
> Intel(R) Standard Manageability Configuration
MEBx Exit
Intel(R) ME Password
Intel(R) ME Password
[↓↑] = Move Highlight
[Enter] = Enter Entry
[Esc] = Exit

2. You will be asked to change the password before setting ME.


Intel(R) Management Engine BIOS Extension v8.0.0.0061/Intel(R) ME v8.1.0.1265
Copyright(C) 2003-12 Intel Corporation. All Rights Reserved.
MAIN MENU
MEBx Login
> Intel(R) ME General Settings
> Intel(R) Standard Manageability Configuration
MEBx Exit
Intel(R) ME Password
Intel(R) ME Password
[↓↑] = Move Highlight
[Enter] = Enter Entry
[Esc] = Exit

3. You must confirm your new password while revising. The new password must contain: (example: **!!11qqQQ**) (default value).

   - Eight characters
   - One upper case
   - One lower case
   - One number
   - One special symbol, such as ! 、 $ or ; ，(、 " , excepted)

   Underline (_) and space are valid characters for password, but they won't make higher complexity.

Intel® iAMT Web Console

1. From a web browser, please type http:///(IP ADDRESS):16992, which connects to Intel® iAMT Web.

   Example: http://10.1.40.214:16992



2. To log on, you will be required to type in username and password for access to the Web.

   USER: admin (default value)
   PASS: (MEBx password)

3. Enter the iAMT Web.



4. Click Remote Control, and select commands on the right side.



5. When you have finished using the iAMT Web console, close the Web browser.